



No.	Part No.	Part Name	Qty	Remarks
1	42011-000184	Grille	1	
2	41207-000029	Top cover	1	
3	92011-000657	Condenser	1	
4	41203-000054	Outdoor motor supporter	1	
5	22001-000049_UM	Outdoor motor	1	
6	42004-000107	Propeller fan	1	
7	41205-000121	Left grille supporter	1	
8	41206-000052	Front plate	1	
9	42011-000038	Fan guard	1	
10	92014-000142	Compressor and accessories	1	
11	92008-000209	4-way valve	1	
12	92007-000969_UM	4-way valve assembly	1	
13	41202-000216	Base	1	
14	41205-000083	Right plate	1	
15	92007-001050	Two-way valve	1	
16	41204-000018	Valve supporter	1	
17	92007-001041_UM	Three-way valve	1	
18	41201-000044	Electronic Box Cover	1	
19	42001-000036	Cable clamp	1	
20	11304-100045_UM	Terminal	1	
21	31201-000988_UM	Outdoor PCB Assembly	1	
22	22011-000002_UM	Inductor	1	
23	92007-002083	Capillary assembly	1	

No.	Part No.	Part Name	Qty	Remarks
24	41208-000141	Partition plate	1	
25	10104-100036	Pipe Temp. sensor and outdoor Temp. sensor	1	Not shown in explosion view
26	10104-100047	Discharge Temp. sensor	1	
27	41204-000051	Valve cover	1	
28	A2005-000530	Base carton	1	
29	A1201-007767	Cabinet carton	1	
30	A1202-000039	Base foaming	1	
31	41213-000030	Cover foaming	1	